


AVT-MF (Mounting Feet Kit) **Revit Model Features**

The ff-wh1.rfa model attached includes the following options in the Model Properties category in the Properties window

| Model Properties | |
|----------------------------|--------|
| Unit Width | 1045.0 |
| Mounting Height | 80.0 |
| End Bracket Centres Length | 1630.4 |

1. **'Unit Width'** lets you adjust the distance in between the bracket across the width to suit the unit in question.

NOTE: This value has already been set if you choose one of the predetermined templates in the list and will therefore not need adjusting.





2. **'Mounting Height'** lets you adjust the between the floor and the bottom of the unit in question. The default value is 80mm.

NOTE: Due to the size of the foot-post the minimum mounting height allowed is 19mm and the maximum is 114mm. Sizes outside of these will be ignored.

NOTE: This parameter will not raise the unit model itself, it will simply drop the feet so the model height will need to be adjusted afterwards.

| | |
|-----------------|------|
| Mounting Height | 25.0 |
|-----------------|------|

| | |
|-----------------|-------|
| Mounting Height | 110.0 |
|-----------------|-------|



3. **'End Bracket Centres Length'** lets you adjust the distance in between the centre points of the end brackets along its length the width to suit the unit in question.

NOTE: This value has already been set if you choose one of the predetermined templates in the list and will therefore not need adjusting.